

# ATWOOD ELECTRIC JACK SYSTEM

Used on Mid-Year 2003 Flair and Storm Products

Used on All 2004 Flair and Storm Products

Used on All 2005 Gas Products

( Southwind, Pace Arrow, Bounder, Flair , Storm )

**except Fiesta & Terra need to Verify type of system used by FIN#**

## **Fleetwood part #**

#396164-Jack-Elect.Leveler (15")  
#416409-Jack-Elect Leveler (13")  
#496688-Jack -Elect Leveler (13" 10K)  
#490315-Jack-Elect Leveler ( 13" 10K)

## **Atwood part #**

V#66280  
V#66302  
V#66375  
V#66070

## **Fleetwood part #**

#385419-Relay-Ctrl - (Ford)  
#384883-Relay-Ctrl - (Ford)  
#384882-Relay-Ctrl - (Wkhrs)  
#496546-Relay-Ctrl - (Wkhrs)  
#514946-Auto Controller  
#472841-Touch Pad only

## **Atwood part #**

V#66205  
V#66272  
V#66276  
V#66330  
V#66324  
V#66273

( Touch Key Pad is part of these Kits \*\*spo from Vendor )

## **Fleetwood part #**

#396163 - Brkt -Lvlr  
#396162 - Brkt -Lvlr  
#470424 - Brkt-Lvlr  
#470426 - Brkt-Lvlr  
#484697 - Brkt-Lvlr  
#470425 - Brkt-Lvlr

## **Atwood part #**

V#61023  
V#61016  
V#61011  
V#61023  
V#61053  
V#6606

Defintion for Jack Legs: DF = Driver Front  
DR = Driver Rear

PR = Passenger Rear  
PF = Passenger Front